




Posición	Código de la pieza	Name
1	192877-8	Portabrocas manual
2	411596-0	PROTECTOR PARA 6300T
6	911256-9	TORNILLO PLANO M5X35*
7	134304-9	CULATA PARA 6300T
9	226012-7	TRANSMISION 13-41
12	211031-6	RODAMIENTO PARA 608LLB
13	156436-2	CARCASA INTERMEDIA 6300T
18	911266-6	TORNILLO M5X45*
19	273482-1	MANGO 37 /6300T
20	211031-6	RODAMIENTO PARA 608LLB
21	263002-9	FIJADOR 4*
22	213002-9	JUNTA ANTIPOLVO 8
23	241015-0	VENTILADOR 68
24	512638-4	INDUCIDO 6300T
25	411234-4	DEFLECTOR PARA 6300T
26	911275-5	TORNILLO M5X50
27	528753-4	FIELD ASS'Y 220V
28	681613-2	ARAND.AISLANTE 806 (320701)*
29	211031-6	RODAMIENTO PARA 608LLB
30	253192-6	ARANDELA PLANA 14*
31	263014-2	FIJADOR 4* GA7000/HM1100
33	855626-1	NAME PLATE 6300T
34	159482-4	CARCASA CPL. JR3000VT
35	643551-6	PORTA ESCOBILLA 5-8*
36	911124-6	TORNILLO M4X14*
37	181026-2	ESCOBILLAS CB-55
38	421144-7	AISLANTE INTERRUPTOR 6300T
39	651315-4	INTERRUPTOR SGEL208M 4014N
41	645253-0	CONDENSADOR B PARA 9541-9542
42	666066-6	POWER SUPPLY CORD 1.0-2-2.5
43	911153-9	TORNILLO M4X28*
44	410068-2	TAPA MANGO JR3000V/6300T
45	911133-5	TORNILLO M4X18*
46	687063-9	PRESILLA PARA 5903R/HR4000C
47	682502-4	SALIDA DE CABLE 8-85 (320800)