

Posición	Código de la pieza	Name
52	324845-5	CIGUEÑAL HK1820
53	211232-6	RODAMIENTO 6002LLU
54	213219-4	JUNTA DE ACEITE 15 HK1810
55	265490-6	TORNILLO HEX. M4X16
56	318202-7	CAJA DE RODAMIENTO HK1820
57	213513-4	JUNTA TORICA 2416S
58	267126-3	ARANDELA PLANA 22 PARA 5603R*
59	267126-3	ARANDELA PLANA 22 PARA 5603R*
60	226675-9	CORONA HELICOIDAL HK1820
61	158523-3	BLOQUE CPL HK1820
62	266041-8	TORNILLO PT M5X25
63	331798-1	GUIA FIJA HK1820
64	424068-6	PLACA AMORTIGUADORA HK1820
65	211131-2	RODAMIENTO 6001DDW
66	253748-5	ARANDELA PLANA 12*
68	513743-0	INDUCIDO HK1820
69	681644-1	ARANDELA AISLANTE
70	210005-4	RODAMIENTO 608DDW
71	450265-8	DEFLECTO HK1820
72	266211-9	TORNILLO M5X40 PARA HK0500
73	625809-5	STATOR HK1820
74	450263-2	CARCASA MOTOR HK1820
75	263002-9	FIJADOR 4*
76	631793-4	CONTROLADOR HK1820
77	645200-1	CONDENSADOR PARA 420S ***
78	638577-1	PORTAESCOBILLA HK1820
79	265995-6	TORNILLO RP 4X18 BGA452
80	194160-9	ESCOBILLAS CB-350 HR4011C
81	450264-0	PROTECTOR TRASERO HK1820
82	265995-6	TORNILLO RP 4X18 BGA452
83	234022-0	MUELLE COMPRESION 14 HR2800
84	265995-6	TORNILLO RP 4X18 BGA452
85	450280-2	GUIA DE MUELLE HK1820
86	450272-1	BASE DEL ASA HK1820
87	450279-7	SOPORTE PROTECTOR POLVA HK1820
88	424069-4	PROTECTOR DE POLVO HK1820
89	450271-3	BOTON DE CIERRE HK1820
90	234040-8	MUELLE COMPRESION 8 HK1820
92	961011-9	GRUPILLA E-4*
93	188495-8	ASA SET HK1820
94	450269-0	PALANCA INTERRUPTOR HK1820
95	158522-5	SOPORTE INTERRUPTOR HK1820
96	650597-5	INTERRUPTOR TG71BS-1 HK1820
97	450267-4	PROTECTOR DEL ASA HK1820
98	265995-6	TORNILLO RP 4X18 BGA452
99	265995-6	TORNILLO RP 4X18 BGA452
100	687169-3	PRESILLA HP1620
101	665883-1	CABLE ALIMENTACION HK0500

102	682573-1	SALIDA DE CABLE 10 GA9010C
103	864601-6	HK1820 NAME PLATE
104	911234-9	TORNILLO PARA 910*
105	266041-8	TORNILLO PT M5X25
106	313139-3	CASQUILLO BULON 6 HR2800
107	266041-8	TORNILLO PT M5X25
1	286283-8	TAPA 38 HK1820
2	233966-1	ANILLO DE CIERRE 19 HK1820
3	450275-5	TAPA MANDRIL HK1820
4	234039-3	MUELLE DE CIERRE 42 HK1820
5	345874-5	GUIA HK1820
6	450274-7	RACOR DE CAMBIO HK1820
7	216002-8	BOLA DE ACERO 4.8*
8	331796-5	CASQUILLO 25 HK1810
9	262142-0	ANILLO DE URETANO 26 HK1820
10	257288-5	ANILLO 21 HK1820/HR3210
11	345873-7	GUIA DE ARANDELA HR3210C
12	233916-6	MUELLE CONICO 21-29 HR2020
13	231985-1	ANILLO DE CIERRE 43 HR5001C
14	450273-9	SOPORTE DEL PROTECTOR HK1820
15	424066-0	PROTECTOR CAÑON HK1820
16	213465-9	JUNTA TORICA 31 HK1820
17	318196-6	CAÑON HK1820
18	213606-7	JUNTA TORICA 48
19	922243-3	TORNILLO ESTRELLA 5*25
20	233956-4	ANILLO DE CIERRE 37 HK1820
21	257296-6	ANILLO 39 HK1820
22	213008-7	JUNTA TORICA 22.4
23	216022-2	BOLA DE ACERO 7.0
24	324837-4	PORTA HERRAMINTAS HK1820
25	268226-2	BULON 6 HR2300
26	324844-7	IMPACTADOR HK1820
27	213128-7	JUNTA 12
28	424065-2	ANILLO DE GOMA HK1820
29	267363-9	ARANDELA PLANA 12 HK1820
30	331849-0	CILINDRO HK1820
31	256862-6	VARILLA CILINDRO 2,5 HK1820
32	331799-9	ANILLO 29 HK1820
33	234041-6	MUELLE COMPRESION 32 HK1820
34	345872-9	ARANDEL TAPA HK1820
35	213435-8	JUNTA TORICA 26 PARA HR3000C
36	324847-1	PERCUTOR HK1820
37	213283-5	JUNTA TORICA HR3210C
38	213283-5	JUNTA TORICA HR3210C
39	256087-2	BULON 7 HK1820
40	213262-3	JUNTA TORICA 18
41	450278-9	BIELA HK1820
42	331797-3	CASQUILLO 29 HK1810
43	450298-3	PISTON HK1810

HK1820 - Martillo mini-demoledor 3,4Kg



44	922148-7	TORNILLO HEX M4X25 HR5211C
45	450277-1	PROTECTOR BLOQUE HK1820
46	419988-7	TAPA DE FILTRO HR2800
47	213218-6	JUNTA TORICA 16 PARA 2414K
48	443129-3	FILTRO HR2800
49	450276-3	TAPA CULATA HK1820
50	911133-5	TORNILLO M4X18*
51	424067-8	JUNTA DE CULATA HK1820