




Posición	Código de la pieza	Name
1	286285-4	CAPUCHON PORTA HERR. HR4011C
2	233948-3	ANILLO DE CIERRE 25 HR5211C
3	257308-5	ANILLO 28 HM1111C
4	450064-8	PROTECTOR PORTABROCAS HR4501C
5	346247-5	ARANDELA 28 HM1111C
6	262161-6	JUNTA CAUCHO 28 HM1111C
7	324752-2	TAPA DE CIERRE HR5201C
8	451836-4	TAPA HM1111C
9	310178-4	CIERRE DE HERRAMIENTA HR5201C
10	345804-6	GUIA DE MUELLE HR5201C
11	234180-2	MUELLE PRESION 47 HM1111C
12	313193-7	ANILLO CAMBIO HM1111C
13	233982-3	ANILLO ELASTICO 33 HM1111C
14	325904-8	ANILLO BLOQUEO HM1111C
15	451842-9	TAPA ANILLO CAMBIO HM1111C
16	451835-6	TAPA CAÑON HM1111C
17	922148-7	TORNILLO HEX M4X25 HR5211C
18	451849-5	TAPA CAÑON HM1101C
19	140411-8	CAÑON COMPLETO HM1111C
20	922353-6	TOR. CAB HEX. M6X30
21	213654-6	JUNTA TORICA 60
22	213492-6	JUNTA TORICA 32 HR5211C
23	213492-6	JUNTA TORICA 32 HR5211C
24	262135-7	ANILLO DE URETANO 36 HR4501C
25	325901-4	PORTAHERRAMIENTAS HM1111C
26	213281-9	RETEN 18 PARA HR4011C
27	213392-0	ANILLO DE FLOURURO 25 HR4000C
28	213317-4	JUNTA TORICA 20 PARA HR4000
30	325902-2	IMPACTADOR HM1111C
31	325903-0	ARANDELA FUNDA HM1111C
32	422053-3	ARANDELA CAUCHO 20 HM1111C
33	325903-0	ARANDELA FUNDA HM1111C
34	412096-3	CASQUILLO HM1111C
35	213606-7	JUNTA TORICA 48
36	318604-7	CASQUILLO CILINDRO HM1111C
37	313194-5	ANILLO 39 HM1111C
38	234178-9	MUELLE PRESION 40 HM1111C
39	325905-6	EMPUJADOR HM1111C
40	213536-2	JUNTA TORICA 27 HM1111C
41	331892-9	CILINDRO 35 HM1111C
42	213458-6	JUNTA TORICA 34
43	233981-5	ANILLO ELASTICO 38 HM1111C
44	267423-7	ARANDELA PLANA 40 HM1111C
45	233981-5	ANILLO ELASTICO 38 HM1111C
46	331911-1	BULON PISTON 10 HM1111C
47	213536-2	JUNTA TORICA 27 HM1111C
48	451833-0	PISTON HM1111C

49	213415-4	JUNTA TORICA 28 PARA HM1100
50	451834-8	BIELA HM1111C
61	424311-3	TAPON FILTRO HM1111C
62	443127-7	FILTRO HM1203C
63	911133-5	TORNILLO M4X18*
64	451838-0	TAPA CARCASA HM1111C
65	424312-1	JUNTA ACEITE HM1111C
66	325899-5	CIGUEÑAL HM1111C
67	211279-0	RODAMIENTO 6303
69	140408-7	BLOQUE MOTOR HM1101C
70	266041-8	TORNILLO PT M5X25
71	419008-7	PERMO GUIA HR4011C
72	423345-3	PLACA DE UNION HR4011C
73	213133-4	JUNTA DE ACEITE 12 HR2800
74	211295-2	RODAMIENTO 6202LLU HM1111C
75	267215-4	ARANDELA PLANA 15 BTW200
77	517858-5	INDUCIDO HM1111C
78	681642-5	ARANDELA AISLANTE PARA LS1013
79	210059-1	RODAMIENTO 6000RD PARA HR4000C
80	451837-2	DEFLECTOR HM1111C
81	266568-8	TORNILLO 5X80 HM1111C
82	623418-4	STATOR 220V PARA HM1111C
83	451840-3	CARCASA MOTOR HM1111C
84	638700-8	PORTAESCOBILLAS HM1111C
85	195844-2	ESCOBILLAS CB-171 HR5211C
86	267215-4	ARANDELA PLANA 15 BTW200
87	451839-8	TAPA TRASERA HM1111C
88	266041-8	TORNILLO PT M5X25
89	265995-6	TORNILLO RP 4X18 BGA452
90	631966-9	CONTROLADOR HM1101C
91	638718-9	LED INDICADOR HM1111C
92	450240-4	LENTE HR3210C HR3210C
99	868072-9	ETIQUETA HM1101C
100	266041-8	TORNILLO PT M5X25
102	140410-0	MANGO COMPLETO HM1101C
105	450897-1	PALANCA DE NIVEL HM1203C
106	232209-8	MUELLE BALLESTA HM0860C
107	450891-3	TOPE INTERRUPTOR HM1203C
108	263027-3	FIJADOR 4* HM0860C
109	654531-7	CLEMA CONEXION 4602D
110	651418-4	INTERRUPTOR ST115A-40 /9541
111	687169-3	PRESILLA HP1620
112	265995-6	TORNILLO RP 4X18 BGA452
113	682560-0	SALIDA DE CABLE PARA HM1202
114	695123-3	CABLE 4MTS.
115	451841-1	TAPA MANGO HM1111C
116	265995-6	TORNILLO RP 4X18 BGA452
117	265439-6	TORNILLO CAB.HEX.M8X150
118	417002-3	CUNA DEL ASA PARA HM1202
119	317282-0	ABRAZADERA ASA 68A HM1111C

120	951166-8	PASADOR 5-24 *
121	317283-8	ABRAZADERA BASE 68B HM1111C
122	417003-1	ASA AUXILIAR PARA HM1202
123	417002-3	CUNA DEL ASA PARA HM1202
124	252640-2	POMO M8 PARA HM1200/B/K