

SPARE PARTS CARD

101276240 PF 4000

PF4000
REV - 00
04-2009

The diagram illustrates the exploded view of the Makita PF4000 submersible pump assembly. The components are numbered as follows:

- 1: Small screw
- 2: Small screw
- 3: Gasket
- 4: O-ring
- 5: Small screw
- 6: Small screw
- 7: Small screw
- 8: Motor housing
- 9: Cable
- 10: Plug
- 11: Plug
- 12: Plug
- 13: Plug
- 14: Plug
- 15: Motor housing
- 16: Motor housing
- 17: Motor housing
- 18: Motor housing
- 19: Motor housing
- 20: Nut
- 21: Washer
- 22: Plug
- 23: Motor housing
- 24: Motor housing
- 25: Motor housing